Parts Manual

Mfg. No: 296442-0001-H1

Copyright © Briggs & Stratton. All Rights reserved

16-Apr-2024

Model Components — Page

Air Cleaner, Intake Manifold. . . . 4
Alternator, Starter Motor, Ignition, Wires. . . . 6
Blower Housing, Flywheel, Debris Guard. . . . 10
Camsahft, Crankshaft, Cylinder, Piston, Rings, Connecting Rod, Breather. . . . 12
Carburetor, Fuel Supply. . . . 14
Controls, Springs, Wire Harness. . . . 18
Crankcase Cover, Sump, Oil Filter, Dip Stick. . . . 20
Cylinder Head, Valves. . . . 22
Engine/Valve Gasket Sets, Carburetor Overhaul Kit. . . . 24
Exhaust, Air Guides. . . . 26
Replacement Engine - Europe, Middle East & Africa. . . . 28
Replacement Engine - US & Canada. . . . 29
Model 29, 30, 35 & 38 Engine Accessories Catalog. . . . 30
- Maintenance Kits. . . . 31
- Lubrication. . . . 33
- Starter Motor Side Outlet Mufflers. . . . 35
- Oil Filter Side Outlet Mufflers. . . . 37
- Oil Filter Side Outlet Manifolds. . . . 39
- Starter Motor Side Outlet Manifolds. . . . 41
- Mufflers. . . . 43
- Center Outlet Mufflers. . . . 45
- Muffler Guards and Shields. . . . 47
- Spark Arrestors and Deflectors. . . . 49
- Muffler Mounting Hardware. . . . 51
- Flywheel and Air Intake Guards. . . . 53
- PTO. . . . 55
- Electrical. . . . 57
- Speed Control. . . . 59

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Air Cleaner, Intake Manifold

Mfg. No: 296442-0001-H1





















Not For Reproduction

Air Cleaner, Intake Manifold

REF NO	PART NO	QTY	DESCRIPTION
11	691556		TUBE, Breather
50	690754		MANIFOLD, Intake
51	691694		GASKET, Intake -(Manifold To Carburetor)
51A	692035		GASKET, Intake
54	690676		SCREW -(Intake Manifold)
122	845885		SPACER, Carburetor
161A	845088		BASE, Air Cleaner
161D	844929		BASE, Air Cleaner
163C	844931		GASKET, Air Cleaner
365	690711		SCREW -(Carburetor)
445	394018S		FILTER, A/C Cartridge
445A	845090		FILTER, A/C Cartridge
467	846431		KNOB, Air Cleaner Cover
536	845198		CLEANER-AIR
643B	844932		RETAINER, Air Cleaner
643C	845087		RETAINER, Air Filter
717	692153		BRACKET, Air Cleaner
833B	691593		SCREW -(Air Cleaner Mounting Strap/Stud)
862	845089		STRAP/STUD, Air Cleaner Mounting
967A	272490S		FILTER, Pre Cleaner
967C	271794S		FILTER, Pre Cleaner
968A	699959		COVER, Air Cleaner
971	807084		SCREW -(Air Cleaner Base to Carburetor/Throttle Body)
996A	844930		SHIELD, Carburetor
1004	841656		DUCT, Air
1046A	843068		PLUG, Blower Housing

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Alternator, Starter Motor, Ignition, Wires

Mfg. No: 296442-0001-H1

























Not For Reproduction

Alternator, Starter Motor, Ignition, Wires

REF NO	PART NO	QTY	DESCRIPTION
309	691564		MOTOR-STARTER -Used Before Code Date 14052800
309A	846451		MOTOR, Starter -Used After Code Date 14052700
309B	844717		MOTOR, Starter
310	496880		SCREW -(Starter Motor) -Used Before Code Date 14052800
333	844548		ARMATURE, Magneto
334	692066		SCREW -(Magneto Armature)
359	691077		WASHER -(Ground Terminal)
373	845823		NUT -(Ground Terminal)
413	691029		NUT -(Starter Motor) -Used Before Code Date 14052800
500	691086		WASHER -(Key Switch)
503	845016		STRAP, Starter
507	691972		INSULATOR
510	496881		DRIVE, Starter -(Steel Pinion Gear) -Used Before Code Date 14052800
520	691084		TERMINAL, Ground
526	692067		SCREW -(Regulator)
529	690744		GROMMET
577	690795		CABLE, Starter
578A	844547		HARNESS, Wiring
635	692076		BOOT, Spark Plug
664	691087		NUT -(Key Switch)
683	691029		NUT -(Starter Solenoid)
697	691902		SCREW -(Starter Motor) (Drive Cap)
727	841313		COVER, Starter Drive
729	690586		CLIP, Wire
732	690688		SCREW -(Starter Drive Cover)
732A	841233		SCREW -(Starter Drive Cover)
813	690635		CLAMP
877	393456		WIRE/CONNECTOR, Alternator -(Dual Circuit)
878	398661		HARNESS, Wiring
892	692318		SWITCH, Key
920	557067		SOLENOID, Starter
990	691959		SET, Key
1051	691124		RING, Retaining -Used Before Code Date 14052800
1054	280275		TIE, Cable
1059	698516		KIT, Screw/Washer
1085	809093		MODULE, Ignition
1090	496813		RETAINER, Brush -Used Before Code Date 14052800

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Alternator, Starter Motor, Ignition, Wires

Mfg. No: 296442-0001-H1





























Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Alternator, Starter Motor, Ignition, Wires

REF NO	PART NO	QTY	DESCRIPTION
1119	691552		SCREW -(Alternator)
1231	692067		SCREW -(Ignition Module)
1232	691077		WASHER -(Control Module)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Blower Housing, Flywheel, Debris Guard

Mfg. No: 296442-0001-H1























1036 EMISSIONS LABEL





Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Blower Housing, Flywheel, Debris Guard

REF NO	PART NO	QTY	DESCRIPTION
23A	841908		FLYWHEEL
56	692085		PULLEY, Rope Starter
57	692086		SPRING, Rewind Starter
58	66574		ROPE, Starter
59	805957		INSERT, Grip
60	808167		GRIP, Starter Rope
73A	841662		SCREEN, Rotating
74	841441		SCREW -(Rotating Screen)
304	842681		HOUSING, Blower
305	692062		SCREW -(Blower Housing)
332	690887		NUT -(Flywheel)
363	19203		PULLER, Flywheel
455	841794		CUP, Flywheel
456	845219		PLATE, Pawl Friction
459	845218		PAWL, Ratchet
493	845729		BRACKET, Mounting
493	691503		BRACKET, Mounting -(Solenoid)
506	807120		SCREW -(Carburetor Cover)
515	691528		SPRING, Pawl
563	841735		SCREW -(Debris Screen Guard)
592	690939		NUT -(Rewind Starter)
608	841729		STARTER, Rewind
879	807460		COVER, Carburetor/EFI
949	845728		GUARD, Debris Screen
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1046A	843068		PLUG, Blower Housing

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Camsahft, Crankshaft, Cylinder, Piston, Rings, Connecting Rod, Breather

Mfg. No: 296442-0001-H1







1036 EMISSIONS LABEL

1058 OPERATOR'S MANUAL

1330 REPAIR MANUAL

1319 WARNING LABEL



***REQUIRED** when replacing parts with warning labels affixed.*











Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Camsahft, Crankshaft, Cylinder, Piston, Rings, Connecting Rod, Breather

REF NO	PART NO	QTY	DESCRIPTION
1	692178		CYLINDER ASSEMBLY
2	808534		KIT, Bushing/Seal -(Magneto Side)
3	805101S		SEAL, Oil -(Magneto Side)
8	808984		BREATHER ASSEMBLY
9	844986		GASKET, Breather
10	690751		SCREW -(Breather Assembly)
11	691556		TUBE, Breather
11A	844921		TUBE, Breather
12	845254		GASKET-CRANKCASE
15	690946		PLUG, Oil Drain -(3/8"-18 NPTF-External 7/16" Sq)
15A	691686		PLUG-OIL DRAIN -(1/4"-18 NPTF - 3/8 External Sq)
15A	691680		PLUG, Oil Drain -(3/8"-18 NPTF - Internal 3/8" Sq)
16	692163		CRANKSHAFT -(Tapered PTO Crankshaft)
17	843827		BEARING, Ball
25	843956		PISTON ASSEMBLY -(.020 Oversize)
25	843951		PISTON ASSEMBLY -(Standard)
26	843957		SET, Ring -(.020 Oversize)
26	843953		SET, Ring -(Standard)
27	690683		LOCK, Piston Pin
28	844541		PIN, Piston
29	807900S		ROD, Connecting
32	690698		SCREW -(Connecting Rod) (Connecting Rod)
45	843379		TAPPET, Valve
46	845649		CAMSHAFT
377	808095		KEY, Flywheel
377A	691639		KEY, Woodruff
439	692154		O-RING, Oil Gallery -(Crankcase Cover/Sump or Cylinder Assembly)
572	690686		BAFFLE, Breather
598	807625		SHIM, End Play -(Crankshaft or Camshaft Bearing)
718	806469		PIN, Locating
741	846085		GEAR, Timing
1025	690689		SPOOL, Governor
1036	-----		Label-Emissions -(Available From A Briggs & Stratton Authorized Dealer)
1058	279771TRI		MANUAL, Operator's
1058	279771WST		MANUAL, Operator's
1319	794467		LABEL, Warning
1330	272144		MANUAL, Repair

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Carburetor, Fuel Supply

Mfg. No: 296442-0001-H1





529A



Not For Reproduction

Carburetor, Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
51	691694		GASKET, Intake -(Manifold To Carburetor)
94	844987		KIT, Idle Mixture
95	690718		SCREW -(Throttle Valve)
97	809007		KIT, Throttle Shaft
98	808177		KIT, Idle Speed
102	692077		GASKET, Carburetor Body
104	690723		PIN, Float Hinge
105	797410		VALVE, Float Needle
108A	844989		VALVE, Choke
109	808398		KIT, Choke Shaft
117	690881		JET, Main -(Standard)
118	844990		JET, Main -(High Altitude) (5000 Feet)
118	809442		JET, Main -(High Altitude) (9000 Feet)
119	690720		SCREW -(Upper Carburetor Body to Lower Carburetor Body)
125	844988		CARBURETOR
130A	690726		VALVE, Throttle
133A	844546		FLOAT, Carburetor
182E	841601		BRACKET-FUEL TANK
182F	691520		BRACKET, Fuel Tank
182H	691524		BRACKET, Fuel Tank
182J	691525		BRACKET, Fuel Tank
182G	841600		BRACKET, Fuel Tank
186	844032		CONNECTOR, Hose
186A	845121		CONNECTOR, Hose
187	791766		LINE, Fuel -(Cut To Required Length)
187C	692106		LINE, Fuel
187D	791744		LINE, Fuel -(Formed Hose)
187E	844556		LINE, Fuel -(Formed Hose)
187F	844560		LINE, Fuel
188A	692056		SCREW -(Control Bracket) (M8x14mm)
190A	692199		SCREW -(Fuel Tank)
210	691370		STRAINER, Fuel
231	690718		SCREW -(Choke Valve)
240A	84001895		FILTER, Fuel
240C	844545		FILTER, Fuel
240B	845125		FILTER, Fuel
255	690721		BUSHING, Choke Shaft
276	690724		WASHER, Sealing -(Governor Crank)
385	807084		SCREW -(Fuel Pump)
387	808656		PUMP, Fuel
467	844618		KNOB, Air Cleaner Cover

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Carburetor, Fuel Supply

Mfg. No: 296442-0001-H1





529A



Not For Reproduction

Carburetor, Fuel Supply

REF NO	PART NO	QTY	DESCRIPTION
480	806660		SCREW -(Tube Clamp) (Clamp)
527	845268		CLAMP, Hose
527A	690423		CLAMP, Tube
528	845267		HOSE, Primer
529A	691527		GROMMET
601A	691038		CLAMP, Hose
628	806660		SCREW -(Fuel Pump Bracket)
633	690722		SEAL, Choke/Throttle Shaft
633B	806131		SEAL, Choke/Throttle Shaft -(Throttle)
674	692062		SCREW -(Fuel Tank Bracket)
788	691559		BRACKET, Fuel Pump
807	805557		SPACER -(Throttle)
918	791880		HOSE, Vacuum
955	807723		PLUG, Carburetor
957	795027		CAP, Fuel Tank
958	692008		VALVE, Fuel Shut Off -(Plastic)
958A	698183		VALVE, Fuel Shut Off -(Plastic)
964	590799		CAP, Connector
968B	844559		COVER, Air Cleaner
972A	845138		TANK, Fuel -(Plastic)
1038	844555		ROD, Fuel Shut Off
1054	280275		TIE, Cable
1091	844448		CAP, Limiter
1165	692056		SCREW -(Clamp)
1425	844712		HOSE, Purge Line
1431	844035		WASHER -(Tube Clamp)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Controls, Springs, Wire Harness

Mfg. No: 296442-0001-H1





























Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Controls, Springs, Wire Harness

REF NO	PART NO	QTY	DESCRIPTION
188	692062		SCREW -(Control Bracket) (M8x18mm)
203	690923		CRANK, Bell
206	691244		NUT, Governor Adjusting
208	808453		ROD, Governor Control
209	690709		SPRING, Governor -(Green)
211A	690707		SPRING, Governed Idle -(White)
212	690712		LINK, Throttle
216	690705		LINK, Choke
222	845305		BRACKET, Control
226	692075		ROD, Choke
227A	845484		LEVER, Governor Control
232	692073		SPRING, Governor Link
234	691723		CLIP, Control Rod
262	692083		SCREW -(Rod Bracket)
265	691024		CLAMP, Casing
267A	841552		SCREW -(Casing Clamp) (M5x12mm)
271	692541		LEVER, Control
278	842122		WASHER -(Governor Control Lever)
280	691526		BRACKET, Fixed Speed
281	690742		PANEL, Control
347	795333		SWITCH, Rocker
432	691509		CAP, Spring
500	691086		WASHER -(Key Switch)
505	844752		NUT -(Governor Control Lever)
529	690744		GROMMET
561	690713		NUT -(Control Lever)
562	690239		BOLT -(Governor Control Lever)
578B	690809		WIRE ASSEMBLY
663	692083		SCREW -(Control Panel)
664	691087		NUT -(Key Switch)
689	691272		SPRING, Friction
774	692067		SCREW -(Stop Wire)
789	691996		HARNESS, Wiring
892	692318		SWITCH, Key
990	691959		SET, Key

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Crankcase Cover, Sump, Oil Filter, Dip Stick

Mfg. No: 296442-0001-H1

















Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Crankcase Cover, Sump, Oil Filter, Dip Stick

REF NO	PART NO	QTY	DESCRIPTION
12	845254		GASKET-CRANKCASE
17	843827		BEARING, Ball
18	844588		COVER, Crankcase
20	805049S		SEAL, Oil -(PTO Side)
22	807362		SCREW -(Crankcase Cover/Sump)
85	841233		SCREW -(Gear Cover)
86	690745		COVER, Gear
239	690233		SWITCH, Oil Pressure
273	690681		SEAL, O-Ring -(Oil Pump)
276B	690704		WASHER
287	692062		SCREW -(Dipstick Tube)
415	794903		PLUG -(1/8"-27 NPTF - EXTERNAL SQ)
439	692154		O-RING, Oil Gallery -(Crankcase Cover/Sump or Cylinder Assembly)
468	690690		SEAL, O-Ring -(Oil Pump Screen)
479	807084		SCREW -(Oil Pump Screen)
523A	693175		DIPSTICK
524	693172		SEAL, O-Ring -(Dipstick Tube)
525A	693174		TUBE, Dipstick
525B	693173		TUBE, Dipstick
552	690701		BUSHING, Governor Crank
552A	806686		BUSHING, Governor Crank
596	691492		SCREW -(Oil Pump)
614	691550		PIN, Cotter
616	806685		CRANK, Governor
691	842826		SEAL, Governor Shaft
737	690679		SCREW -(Oil Filter Adapter)
988	692063		GASKET, Oil Adapter
1017	690900		SCREEN, Oil Pump
1024	843825		PUMP, Oil
1027	842921		FILTER, Oil
1028	808235		ADAPTER, Oil Filter

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Cylinder Head, Valves

Mfg. No: 296442-0001-H1





Not For Reproduction

Cylinder Head, Valves

REF NO	PART NO	QTY	DESCRIPTION
5	809200		HEAD, Cylinder -(Cylinder 1)
5A	809201		HEAD, Cylinder -(Cylinder 2)
7	806085S		GASKET, Cylinder Head
13	692059		SCREW -(Cylinder Head)
21	809500		CAP, Oil Fill
33	807681		VALVE, Exhaust
34	807680		VALVE, Intake
35	692084		SPRING, Valve -(Intake)
36	692084		SPRING, Valve -(Exhaust)
40	844895		RETAINER, Valve
40A	692058		RETAINER, Valve
42	807683		KEEPER, Valve
45	843379		TAPPET, Valve
151	841185		STUD -(Exhaust Manifold)
187	791766		LINE, Fuel -(Cut To Required Length)
192	807623		ADJUSTER. Rocker Arm
276A	807085		WASHER, Sealing
337	792015		PLUG, Spark
383	19576S		WRENCH, Spark Plug
635	692076		BOOT, Spark Plug
830	809157		STUD, Rocker Arm -(Rocker Arm)
868	691963		SEAL, Valve
883	691613		GASKET, Exhaust
918	791880		HOSE, Vacuum
1022	806039S		GASKET, Rocker Cover
1023B	691494		COVER, Rocker
1023C	690910		COVER, Rocker
1026	691758		ROD, Push -(Exhaust)(Aluminum)
1026	691836		ROD, Push -(Steel)
1029	807323		ARM, Rocker
1100	791959		PIVOT, Rocker Arm
1176	842067		NUT -(Exhaust Manifold)
1254	807084		SCREW -(Rocker Arm Stud) (Used on Stud For Rocker Cover)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Engine/Valve Gasket Sets, Carburetor Overhaul Kit

Mfg. No: 296442-0001-H1

121 CARBURETOR OVERHAUL KIT



1095 VALVE GASKET SET



358 ENGINE GASKET SET



Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Engine/Valve Gasket Sets, Carburetor Overhaul Kit

REF NO	PART NO	QTY	DESCRIPTION
3	805101S		SEAL, Oil -(Magneto Side)
7	806085S		GASKET, Cylinder Head
9	844986		GASKET, Breather
12	845254		GASKET-CRANKCASE
20	805049S		SEAL, Oil -(PTO Side)
51A	692035		GASKET, Intake
94	844987		KIT, Idle Mixture
102	692077		GASKET, Carburetor Body
104	690723		PIN, Float Hinge
105	797410		VALVE, Float Needle
121	842877		KIT, Carburetor Overhaul
255	690721		BUSHING, Choke Shaft
273	690681		SEAL, O-Ring -(Oil Pump)
276A	807085		WASHER, Sealing
358	808704		GASKET SET, Engine
439	692154		O-RING, Oil Gallery -(Crankcase Cover/Sump or Cylinder Assembly)
468	690690		SEAL, O-Ring -(Oil Pump Screen)
524	693172		SEAL, O-Ring -(Dipstick Tube)
633	690722		SEAL, Choke/Throttle Shaft
633B	806131		SEAL, Choke/Throttle Shaft -(Throttle)
691	842826		SEAL, Governor Shaft
807	805557		SPACER -(Throttle)
868	691963		SEAL, Valve
883	691613		GASKET, Exhaust
988	692063		GASKET, Oil Adapter
1022	806039S		GASKET, Rocker Cover
1091	844448		CAP, Limiter
1095	842723		GASKET SET, Valve

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Exhaust, Air Guides

Mfg. No: 296442-0001-H1





















Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Exhaust, Air Guides

REF NO	PART NO	QTY	DESCRIPTION
37	841309		GUARD, Flywheel
78	690688		SCREW -(Flywheel Guard)
197	807163		SCREW -(Back Plate)
215	841183		GUIDE, Air -(Cylinder 1)(Black)
215F	841182		GUIDE, Air -(Cylinder 2)(Black)
300A	692099		MUFFLER
436	692061		MANIFOLD, Exhaust
437	691902		SCREW -(Exhaust Manifold)
573	841310		PLATE, Back
676	795036		DEFLECTOR, Muffler
677	690661		SCREW -(Muffler Deflector)
727	841313		COVER, Starter Drive
732	690688		SCREW -(Starter Drive Cover)
732A	841233		SCREW -(Starter Drive Cover)
819	692056		SCREW -(Muffler Bracket)
819A	692067		SCREW -(Muffler Bracket)
863A	691513		BRACKET, Muffler
865	843768		COVER, Air Guide
878	398661		HARNESS, Wiring
883	691613		GASKET, Exhaust
884	690898		CLAMP, Muffler
994	794945		ARRESTOR, Spark
1119	691552		SCREW -(Alternator)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Replacement Engine - Europe, Middle East & Africa

REF NO	PART NO	QTY	DESCRIPTION
	2964420012H5U0001		Replacement Engine

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

REF NO	PART NO	QTY	DESCRIPTION

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Model 29, 30, 35 & 38 Engine Accessories Catalog

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

16-Apr-2024





Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Maintenance Kits

REF NO	PART NO	QTY	DESCRIPTION
9000	84004936		KIT, Maintenance -(Non-Oil Guard™ Engines) (20 - 23 HP)
9000A	84004937		KIT, Maintenance -(Non-Oil Guard™ Engines) (12.5 - 18 HP)
9000B	84002315		KIT, Maintenance -(Non-Oil Guard™ Engines)
240	845125	1	FILTER, Fuel
240A	84001895	1	FILTER, Fuel
337	491055S	2	PLUG, Spark
337	84007216	2	PLUG, SPARK -(China Only)
445	692519	1	FILTER, A/C Cartridge -"Professional / PXi" & "Commercial / CXi".
445A	394018S	1	FILTER, A/C Cartridge -"Professional / PXi" & "Commercial / CXi".
445B	841497	1	FILTER, A/C Cartridge -"Professional / PXi" & "Commercial / CXi".
967	692520	1	FILTER, Pre Cleaner
967A	272490S	1	FILTER, Pre Cleaner
1027	842921	1	FILTER, Oil -(Vanguard®)
1505	100169		OIL-1QT VANGUARD (CASE) -(1 qt. Bottle)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved



Not For Reproduction

Lubrication

REF NO	PART NO	QTY	DESCRIPTION
186	796532	1	CONNECTOR, Hose -(Threaded Engine Block Connector for EZ-Oil Drain Hose)(Order hose separate)
239	690233	1	SWITCH, Oil Pressure -(2-4 PSI Normally-Closed Switch)
239A	491657S	1	SWITCH, Oil Pressure -(3-5 PSI Normally-Closed Switch)
239B	841281	1	SWITCH, Oil Pressure -(7-10 PSI Normally-Closed Switch)
239C	694115	1	SWITCH, Oil Pressure -(9-13 PSI Normally-Closed Switch)
239D	697049	1	SWITCH, Oil Pressure -(3-6 PSI Normally-Open Switch)
295	492061	1	ADAPTER, Remote Oil Filter -(Remote oil filter head with 18" (48 cm) hoses)
295	492062	1	ADAPTER, Remote Oil Filter -(Remote oil filter head with 30" (76 cm) hoses)
512	594200	1	HOSE, Oil Drain -(EZ-Oil Drain Hose, 10.5")(Order threaded engine block connector separate)
512	593635	1	HOSE, Oil Drain -(EZ-Oil Drain Hose, 13.75")(Order threaded engine block connector separate)
512B	1723165SM	1	HOSE, Oil Drain, 10-1/2" Long, 3/8-18 Fittings -(10.5")
512C	5048681SM	1	HOSE, OIL DRAIN -(12.5")
517	593633	1	RETAINER, Oil Drain
988	692063	1	GASKET, Oil Adapter
1027	492932S	1	FILTER, Oil
1028	492687	1	ADAPTER, Oil Filter -(Adapter Kit for mounting remote oil filter)
1028A	495244	1	ADAPTER-OIL FILTER -(Remote oil filter mounting head with fittings)
1346	844802	1	VALVE, Oil Drain Shut Off
1346A	492031	1	VALVE, Oil Drain Shut Off
1346B	5401WEB	1	VALVE, Oil Drain Shut Off -(1/4 Turn Oil Drain Valve with Hose)
1505	100169		OIL-1QT VANGUARD (CASE) -(1 qt. Bottle)
1505A	100170		OIL-5QT VANGUARD (CASE) -(5 qt. Bottle)
1600	494724	2	HOSE, Remote Oil Filter -(Hoses only (2) 18" (48 cm))
1600	494725	2	HOSE, Remote Oil Filter -(Hoses only (2) 30" (76 cm))

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved











Not For Reproduction

Starter Motor Side Outlet Mufflers

REF NO	PART NO	QTY	DESCRIPTION
300	690931	1	MUFFLER -(Super Lo-Tone) (Horizontal: 3054, 3564)
300A	690906	1	MUFFLER -(Super Lo-Tone) (Horizontal: 3054, 3564)
300B	808705	1	MUFFLER -(5" Round) (Horizontal: 3854, 3864)
300C	845873	1	MUFFLER -(5" Round, Stainless Steel) (Horizontal: 3854, 3864)
300D	995005	1	MUFFLER ASSY -(Lo-Tone) (Horizontal: 3054, 3564)
300E	692099	1	MUFFLER -(Lo Mount)
436	691499	1	MANIFOLD, Exhaust -(Cylinder 1) (Side Outlet)
740	793859	1	NUT
819	692056	2	SCREW -(Muffler Bracket) (M8x1.25)
819A	691514	2	SCREW -(Muffler Bracket) (M6 X 1.0)
837	808085	2	SPACER, Muffler -(Includes 2)
863	690756	1	BRACKET, Muffler -(Cylinder 1) (Side Outlet)
882	692074	2	FLANGE, Exhaust
882A	806965	2	FLANGE, Exhaust
883	806425	2	GASKET, Exhaust
884	690898	1	CLAMP, Muffler

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved















Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Oil Filter Side Outlet Mufflers

REF NO	PART NO	QTY	DESCRIPTION
300	995002	1	HIGH MNT SPR LO-TONE OIL FLTR SIDE -(Super Lo-Tone) (Horizontal: 3054, 3564) (Vertical: 3567)
300A	995000	1	OIL FILTER SIDE LO-MT -(Lo-Tone) (Horizontal: 3054, 3564) (Requires 808033 Oil Filter Adaptor)
300B	995004	1	HI MNT SPR LO-TONE OIL FLT SIDE -(Super Lo-Tone) (Horizontal: 3854, 3864) (Vertical: 3867)
300C	995009	1	COMMERCIAL MOWERS KIT -(For Wide Area Walker) (Vertical: 3567)
300D	995010	1	COMMERCIAL MOWERS KIT -(Vertical: 3867)
300E	808896	1	MUFFLER
300F	691562	1	MUFFLER -(Super Lo-Tone) (Horizontal: 3054, 3564)
300G	498984S	1	MUFFLER -(Super Lo Tone)
300H	692099	1	MUFFLER -(Lo Mount)
300I	807953	1	MUFFLER
355	842122	2	WASHER -(Muffler Bracket)
436	805609	1	MANIFOLD, Exhaust -(Cylinder 2) (Side Outlet)
436A	692061	1	MANIFOLD, Exhaust -(Cylinder 2) (Side Outlet)
436B	808916	1	MANIFOLD, Exhaust -(Cylinder 2) (Side Outlet)
436C	805778	1	MANIFOLD, Exhaust -(Wide Area Walker)
437	691902	4	SCREW -(Exhaust Manifold)
710	807689	1	COVER, Oil Filter
725	806102	1	SHIELD, Heat
728	690297	2	SCREW
740	793859	1	NUT
819	691514	2	SCREW -(Muffler Bracket) (M6 X 1.0)
819A	807084	2	SCREW -(Muffler Bracket)
819B	692056	2	SCREW -(Muffler Bracket) (M8x1.25)
819C	692062	2	SCREW -(Muffler Bracket)
837	808085	2	SPACER, Muffler -(Includes 2)
863	806759	1	BRACKET, Muffler
863A	691513	1	BRACKET, Muffler
882	692074	2	FLANGE, Exhaust -(3054 & 3564)
882A	806965	2	FLANGE, Exhaust
883	691613	2	GASKET, Exhaust
884	690898	1	CLAMP, Muffler
884A	691956	1	CLAMP, Muffler
988	690687	1	GASKET, Oil Adapter

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

436



436A



436B



436C



436D



Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Oil Filter Side Outlet Manifolds

REF NO	PART NO	QTY	DESCRIPTION
436	805609	1	MANIFOLD, Exhaust -(Vertical: 3567)
436A	692061	1	MANIFOLD, Exhaust -(Horizontal: 3054, 3564)
436B	691501	1	MANIFOLD, Exhaust -(Horizontal: 3054, 3564)
436C	808908	1	MANIFOLD, Exhaust -(Horizontal: 3854, 3864)
436D	808916	1	MANIFOLD, Exhaust -(Horizontal: 3854, 3864) (Vertical: 3867)
437	691902	4	SCREW -(Exhaust Manifold)
882	692074	2	FLANGE, Exhaust
883	691613	2	GASKET, Exhaust

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

436



436A



436B



Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Starter Motor Side Outlet Manifolds

REF NO	PART NO	QTY	DESCRIPTION
436	691502	1	MANIFOLD, Exhaust -(Horizontal: 3054, 3564)
436A	691499	1	MANIFOLD, Exhaust -(Horizontal: 3054, 3564)
436B	808909	1	MANIFOLD, Exhaust -(Horizontal: 3854, 3864) (Vertical: 3867)
882	692074	2	FLANGE, Exhaust

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved



Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Mufflers

REF NO	PART NO	QTY	DESCRIPTION
300	995018	1	MUFFLER -(Inlet I.D. 1.14" (28.9mm))
740	793859	1	NUT
819	807084	4	SCREW
884	691956	1	CLAMP, Muffler

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved



Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Center Outlet Mufflers

REF NO	PART NO	QTY	DESCRIPTION
300	808911	1	MUFFLER -(5" Round) (Horizontal: 3854, 3864)
837	808085	2	SPACER, Muffler
882	806965	2	FLANGE, Exhaust

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved





Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Muffler Guards and Shields

REF NO	PART NO	QTY	DESCRIPTION
725	846568	1	SHIELD, Heat -(For 5" Round Mufflers) (Horizontal: 3854, 3864)
832	691571	1	GUARD, Muffler -(Assembly for 690906 & 691562) (Horizontal: 3054, 3564)
836	692067	4	SCREW

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved













Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Spark Arrestors and Deflectors

REF NO	PART NO	QTY	DESCRIPTION
346	794845	4	SCREW -(Spark Arrestor)
676	396903	1	DEFLECTOR, Muffler -(Direct Outlet) (Face Mounting with 4 Screws)
676A	795036	1	DEFLECTOR, Muffler -(Deflector 90 Degree) (Face Mounting with 4 Screws)
676B	795038	1	DEFLECTOR, Muffler -(Deflector Louvered) (Face Mounting with 4 Screws)
676C	495518	1	DEFLECTOR, Muffler -(Elbow for Muffler Assembly) (For Exit Pipe O.D. of 1.10" (28mm))
677	794845	4	SCREW -(Muffler Deflector)
677A	810079	1	SCREW -(Muffler Deflector)
994	794945	1	ARRESTOR, Spark -(Spark Arrestor) (Face Mounting with 4 Screws)
994A	594562	1	ARRESTOR-SPARK -(Spark Arrester) (For Exit Pipe O.D. of 1.10" (28mm))

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

613

1177

296



883

883A

882



882A



Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Muffler Mounting Hardware

REF NO	PART NO	QTY	DESCRIPTION
296	841185	4	STUD -(Mounting Mufflers)
613	691902	4	SCREW -(Mounting Mufflers)
882	692074	2	FLANGE, Exhaust -(3054 & 3564)
882A	806965	2	FLANGE, Exhaust -(3854 & 3864)
883	806425	2	GASKET, Exhaust -(Horizontal: 3854, 3864) (Vertical: 3567)
883A	691613	2	GASKET, Exhaust -(Horizontal: 3054, 3564) (Vertical: 3567)
1177	842067	4	NUT -(Required if Using 841185)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved







Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Flywheel and Air Intake Guards

REF NO	PART NO	QTY	DESCRIPTION
493	845729	4	BRACKET, Mounting
563	841441	4	SCREW
805	843024	1	MINDER, Filter -(For Engines with Cyclonic Air Filter)
930	846284	1	GUARD, Flywheel Fan
949	845728	1	GUARD, Debris Screen -(Vertical: 3867)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved





Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

PTO

REF NO	PART NO	QTY	DESCRIPTION
73	841582	1	SCREEN, Rotating
73A	494439	1	SCREEN, Rotating
74	841441	4	SCREW -(Rotating Screen)
74A	691647	4	SCREW -(Rotating Screen)
332	690887	1	NUT -(Flywheel)
668	691500	4	SPACER -(Rotating Screen)
668A	691215	4	SPACER -(Rotating Screen)
718	841581	1	PIN, Locating -(32MM)
849	691088	2	SCREW -(Stub Shaft)
849A	846236	2	SCREW -(Stub Shaft)
1047	841580	1	SHAFT, Stub -(1" Diameter) (4.75" Length)
1047A	842655	1	SHAFT, Stub -(1" Diameter) (5.43" Length)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

789



789A



789B



789C



415

578



LOOSE CONNECTOR:
TE # 1-480704-0
MATE-N-LOK 6 POSITION HOUSING

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Electrical

REF NO	PART NO	QTY	DESCRIPTION
415	1714480SM	1	PLUG -(Plug for Ignition Switch Removal)
578	84007350	1	WIRE ASSEMBLY -(Aids in Repowering Engine Application with 6-Pin Connector and Wires with Terminals to Create Custom Adapter Configurations)
789	691996	1	HARNESS, Wiring -(For 16 Amp Alternators)
789A	841318	1	HARNESS, Wiring -(For 16 Amp Alternators with Solenoid Shift Starter)
789B	847601	1	HARNESS, Wiring -(For 20 Amp Alternators)
789C	847602	1	HARNESS, Wiring -(For 20 Amp Alternators with Solenoid Shift Starter)

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved



Not For Reproduction

Speed Control

REF NO	PART NO	QTY	DESCRIPTION
262	841552	1	SCREW
265	691024	1	CLAMP, Casing -(Casing Clamp for Hard Casing)
265A	690798	1	CLAMP, Casing -(Casing Clamp for Soft Casing)
267	792629	1	SCREW -(Screw for Casing Clamp)
268	691025	1	CASING, Control Wire -(Wire Casing 72")
269	26634	1	WIRE, Control -(Control Wire 78")
269A	93907	1	WIRE, Control -(Control Wire 100")
270	691027	1	NUT -(Nut for Wire Casing)
271	691028	1	LEVER, Control -(Speed Control Lever Assembly)
271A	692105	1	LEVER, Control -(Speed Control Lever Assembly) ('L' Shaped End)
271B	692541	1	LEVER, Control -(Speed Control Lever Assembly) ('Z' Shaped End)
281	690742	1	PANEL, Control
347	691995	1	SWITCH-ROCKER
356	690796	1	WIRE, Stop
356A	691999	1	WIRE ASSEMBLY
416	595196	1	BRACKET, Throttle Cable -(Casing Clamp for Snap-In Casing)
416A	84006945	1	BRACKET, Throttle Cable
561	806447	1	NUT
620	494052	1	BRACKET, Control -(Throttle Control for Vanguard V-Twin Horizontal Small Block)
1619	691693	1	SCREW

Not For Reproduction

Copyright © Briggs & Stratton. All Rights reserved

Copyright © Briggs & Stratton. All Rights reserved

16-Apr-2024